


Product code

18-530-WH-TK



Item Description	Cosiloft 100 White and Teak Fire Pit Bar Table
Barcode	8712757463701
Factory	GIME002
Country of Origin	China
Assembly Required	Yes
Testing Details	Burner: EN 14543:2017; Regulator: EU/2016/426 A III B (09.03.2016) DIN EN 16129 (01.08.2013)
Packaging Materials	Carton; foam; bubble wrap
Colour Group	White
Aerocover	18-530-C
Web Description	<p>The Cosiloft 100 Bar Table is perfect as a relaxed table to stand around in classic bar style. This model comes with a classic white base and luxury teak wood top, with a gas fire as its centrepiece. Each Cosiloft 100 comes with a plate to cover the burner unit, meaning you can use the entire bar table to place food and drinks on. It has an easy to use, electronic ignition that works on battery. This fits a gas bottle of up to 5KG, which is easy to place in the hidden compartment.</p> <p>Whilst we do offer a weatherproof cover to fit the Cosiloft 100 Bar Table White And Teak, we would not recommend using these on the teak topped tables. Teak is a hardwood and as such, completely happy in the atmosphere and will age naturally and beautifully when left to the elements. As your Cosi product is completely weatherproof, you can confidently leave it uncovered.</p> <p>The glass surround and cover plate are all sold separately. You can order these with the below codes.</p> <p>Cosiglass Set Square Fire Pit Large: 18-504</p> <p>Cosi Cover Plate Glass Set Large: 18-616-L</p>

Single Item Dimensions (CM) (KG)	
Width	100
Depth	100
Height	105
Weight	38
Single Item Colour	
Frame/Item	White / Teak
Fabric	
Single Item Materials	
Item/Frame	Aluminium
Fabric	
Additional Details	
Supplier part number: 5980120	

Product code

18-530-WH-TK

Battery Information	
Are Batteries Included	Yes
Type of Batteries	1.5 V, AA
Qty of Batteries	1

Packaging Details (CM) (KG)	
Number of Product Boxes	3
Product Box 1	
Content	1 Cosiloft 100 bar table white base including stainless steel burner, lava rocks, top plate for burner, 4 pcs ceramic wood logs, gas hose and regulator, manual and battery
Width	57
Depth	57
Height	128
Weight	29
Product Box 2	
Content	1 Cosiloft 100 bar table table top frame white for table top 100x100cm
Width	107
Depth	107
Height	9
Weight	3.5
Product Box 3	
Content	1 Cosi table top teak 100x100cm
Width	106
Depth	106
Height	9
Weight	14.5
Item Labels Positions	
Battery Warnings	No
UKCA/CE Symbol	CE/UKCA: CE Yes; UKCA in progress
WEEE	No
Polybag Warnings	No
Care Instructions	

<p>Maintenance instructions Cosi Teak items</p> <p>Congratulations on the purchase of your Cosi! Read these user and maintenance instructions very carefully.</p> <p>With these maintenance tips in mind you will be able to enjoy your Cosi for many years to come.</p> <p>Teak is a product from nature and lives its own life: it shrinks and expands, creating spaces between the various glued parts. This is due to the air humidity. By exposing Teak to weather effects, the Teak wood will develop its own grey colour when the Teak wood is not protected with a protector. During use circles and spots cannot be prevented and the formation of cracks in the Teak is inevitable. Teak slats will never remain 100% flat, creating unique features such as the curling upwards on the corners of the table. These are characteristics of the type of wood. Due to the strong construction you will be able to enjoy it for many years to come</p> <p>Maintenance instructions</p> <ol style="list-style-type: none"> 1. It is not recommended to cover the Teak top, this can cause ugly sites. Do you prefer to use a protection cover? Please keep in mind that Teak wood is never in direct contact with the protection cover. You can place the glass set between cover and Teak top for example, to avoid the cover touching the Teak wood. <ul style="list-style-type: none"> - Avoid stagnant water on top of the protection cover. - Ventilate the firepit on a regular basis by removing the cover from the table. <ol style="list-style-type: none"> - If the cover is used incorrectly on the Teak wood, mould stains can occur. 2. Do not place objects on the Teak wood for long time. Think of flowerpots, vases, drink glasses and accessories. These objects could cause circles and stains. Use coasters if possible. 3. Treat the Teak wood regularly with Teak shield, Teak protector, or Teak grey wash. <p>Teak wood maintenance</p> <p>Teak shield</p> <p>By applying a layer of Teak shield, you can make your teak and hardwood water and dirt repellent to ensure longterm protection and to prevent stains. Teak shield is an almost invisible wood impregnator that makes it difficult for wine, olive oil or butter to seep into the Teak. This product helps to prevent stains while keeping the natural look of the surface. In addition, the Teak shield allows moisture vapour transmission and is included with builtin mould and mildew inhibitor. You only need to apply Teak Shield a few times a year. For maximum results, treat the tabletop a few times more.</p> <p>Teak protector</p> <p>Teak wood has the natural effect of turning grey after some time outside. If you want to keep the natural brown Teak colour, you can treat the Teak tabletop with a Teak protector. With a Teak protector the tabletop will maintain the golden brown colour of Teak for a longer time.</p> <p>Teak grey wash</p> <p>Do you like an aged look? Teak grey wash turns brown Teak wood into old, grey Teak wood. We strongly recommend treating the surface with Teak shield to prevent stains.</p> <p>Always read the instructions of the maintenance product very carefully, we recommend using the products of</p> <p>Golden Care.</p> <p>Cleaning advice</p> <ol style="list-style-type: none"> 1. Never use a high-pressure cleaner to clean the Teak. This will cause the Teak to break and feel rough. 2. Preferably clean the Teak wood on a rainy day, this makes it easier to clean it because the dirt has already been soaked and loosened. You can also make the Teak wood thoroughly wet by yourself. 3. Dissolve a cup of table salt in a bucket of lukewarm water. 4. Scrub the Teak wood with the salt water and a stiff brush. 5. Rinse the Teak with copious amounts of water. 6. Afterwards when the Teak is completely dry, you can choose to treat the Teak with Teak Protector, Teak shield or Teak grey wash. 7. Always read the instructions on the packaging of the maintenance product very carefully. 	
--	--